



USE 10 AWG FOR 30A SERVICE, USE 8 AWG FOR 50A SERVICE

USE 14 AWG MINIMUM
 USE 12 AWG FOR UP TO 23 AMP.
 USE 10 AWG FOR UP TO 30 AMP.
 USE 8 AWG FOR UP TO 50 AMP.

6-30-92
 02-27-92
 9-10-12-88

* FUSE AT BATTERY WITH 1A FUSE

TO GROUND - DC
 TO BATT. SWITCH COMMON
 (+ 12 VDC FUSE AT BATTERY OR SOURCE 70AMPS MAX FUSE SIZE)

ES - 3 PANEL

D02010300 B

NEWMAR

U.S.A:
 P.O. Box 1306
 Newport Beach, CA 92663
 Phone: (714) 751-0488
 Fax: (714) 957-1621