


TGS-25 Temperature Sensor

For use with model TG-3 Instrument




Notes and Warnings

1) Connect the first temperature sensor to screw terminal D.

2) If you have fewer than three sensors, leave the spare terminals (E and/or F) disconnected (floating).

Screw Terminal
(On Case Back)

All Wires AWG
14-22 Gauge (0.6 - 1.5 mm)



NEWMAR®

DC Power Onboard
Emergency & Specialty Vehicles
www.newmarEVpower.com

M-TGS-25
As of May 2010

P.O. Box 1306
Newport Beach
California 92663

Phone: 714-751-0488
Fax: 714-957-1621
E-Mail: techservice@newmarpower.com